# HRX 075 Filter cleaning

Rotors · https://husqvarna-water.com/knowledgebase/hrx-075-filter-cleaning/

1. Remove grass and dirt around the sprinkler head so you can see the top 1 ½ inches.
2. Unscrew the cap and remove the stem assembly.
3. Use pliers to extract the filter from the bottom of the stem assembly.
4. Clean out debris and replace the filter.
5. Replace the stem assembly to the sprinkler body and screw it tightly.