HRC 100 Rain Delay

HRC 100 · https://husqvarna-water.com/knowledgebase/hrc-100-rain-delay/

[RAIN DELAY] allows you to delay your sprinkler controller from watering for a set period of time. Delay settings are 24, 48, and 72 hours.

- Turn the dial to [RUN]
- Press the [RAIN DELAY] button to automatically delay watering for 24 hours
- If a longer Rain Delay is desired, press the arrow buttons to increase or decrease the setting.
- Press [ENTER] or wait 10 seconds and the selected rain delay will begin.
- [CLEAR] button stops the rain delay and scheduled watering will resume.
- At the end of the selected rain delay amount of time, automatic watering resumes.
- While in rain delay mode, the controller display will switch between the actual time and the remaining hours of the delay, every 2 seconds