HRC 410 LED Codes

HRC 410 · https://husqvarna-water.com/knowledgebase/hrc-410-led-codes/

Color and 8 segment LCD definitions:

"b" Button	Panel (top right)	Definition
Flashing Blue	P	Pairing mode enabled
Solid White	Nothing (no LED code)	Idle mode Waiting for program or command
Flashing White	Clockwise trailing	Connecting to Wi-Fi or Server
Green	Station Solid	Station is currently watering
Yellow	D	Currently as a rain delay
Flashing Red, white, and Blue	Clockwise Trailing	Identify mode has been turned on
Flashing Red	Nothing (no LED code)	Timer is Off
Red	F then Station	Indicates a fault on the zone that flashes


8
b·hyve
PRO
HYDRO·RAIN
HRC 410